



Epson TM-C3400 Color Label Printer Install Guide



EPSON®
EXCEED YOUR VISION

tsi
THERMAL
SOLUTIONS
INTERNATIONAL, INC.
EXCEEDING YOUR
EXPECTATIONS



Printer Setup – Unbox & Load Ink Cartridge

- **Unbox printer**

- Attach power cable
- DO NOT attach USB cable
- DO NOT power on

- **Load Ink Cartridge
(use starter cartridge first)**

- Open Front of Ink Cartridge Compartment
- Slide in the Ink Cartridge & close the door



**Starter cartridge must
be replaced before
completing install**



Printer Setup – Load Paper

- Loading Roll-Fed Print Media
 - A – Open Front Compartment



- B – Place the label roll with the labels pointing up and close the compartment.







Printer Setup – Install Epson Driver

- **Install Epson TM-C3400 Printer Driver**

- Please select from the 32Bit or 64Bit Printer Driver
- Decompress Drivers\Installation Package
- Select Epson TM-C3400 Printer and Press Ok.
- Accept Terms and License Agreement.
- Accept typical & default settings.
- When prompted, connect the printer to the PC via USB cable.
- When the Driver Wizard Finishes, the printer install will be complete.

c34d32_1300	4/19/2011 7:12 PM	Application	13,636 KB
c34d64_1300	4/19/2011 7:14 PM	Application	14,492 KB






Printer Setup – Configure Epson Driver

- Install Epson TM-C3400 Printer Driver

- Open Epson printer preferences



- Select Add/Del in the Media Layout section






Printer Setup – Configure Epson Driver *continued*

Create new media layout for
4 x 8 UPS Label


- Enter Media Layout Name
- Using the up/down arrows
 - Enter 102.0 as shown
 - Enter 204.5 as shown
- Click Add
- Click OK





Printer Setup – Configure Epson Driver continued


- At “Media Layout” select
4 x 8 UPS Label.....
from the drop down menu
- At “Media Source” select
Roll Media - Labels on a roll.....





Printer Setup – Configure Epson Driver continued

- Click Media Layout Option
- Check “Auto fit to Page”
- Click OK





Before Leaving New Install

- Make sure to remove the starter ink cartridge used for install & testing. Please direct the customer to complete this so you can ensure they have been trained. Also ensure they are clear on reloading labels.
- Make sure the customer knows who to contact in case of a printer malfunction. The AE should be the primary contact in most cases. Marketing, Customer Solutions & TSG resources will support the installation where necessary, but it is always prudent, when converting to a new methodology, to have a backup in place to prevent unforeseen events from delaying shipments.
- Reordering supply kits is straightforward:
 - Contact Chance Raines – sales@tsiamerica.com or 855-877-2577
 - Part number is 48125-21P – Kit includes 1000 Roll Format Labels & 1 Ink Cartridge.
 - Price is \$70.00 – payable by credit card




Additional Information




Printer Setup – Fanfold Configuration

- **To change from Roll Media to Fanfold Media**

- Open the fanfold paper cover and remove the paper feed guide.



- Open the front paper roll cover.






Printer Setup – Fanfold Configuration


- To change from Roll Media... continued...

- Insert the paper feed guide into the grooves inside the paper roll cover.



- Close the paper roll cover.


- Turn the printer off. Open the ink cartridge cover. Remove the small rubber grommet. Switch DIP switch 3 to ON.





Printer Setup – Configure Driver for Fanfold

- At “Media Layout” select
4 x 8 UPS Label.....
from the drop down menu



- At “Media Source” select
Rear Feed Slot- Fan Fold Labels



Printer Setup – Fan Fold Configuration

- Load Label Media (fanfold)

- Open Back Compartment of Printer and Feed the Fanfold Labels thru to the front of the printer. Close the back compartment
- Power printer on




- Once the labels are fed through the front of the printer, press the feed button so the labels are adjusted correctly




Printer Setup – Fanfold to Roll Media

- To change from Fanfold Media

- Open the front paper roll cover.



- Remove the “Paper Feed Guide” from the grooves inside the paper roll cover.







Printer Setup – Fanfold to Roll Media

- **Change from Fanfold Media...continued...**

- Open the fanfold paper cover and place the paper feed guide. Close fanfold paper cover.



- Open the ink cartridge cover. Remove the small rubber grommet. Switch Dip switch 3 to OFF.





Epson TM-C3400 Printer Specs

- Printer Specs

- Printer Resolution – 360dpi x 180dpi, 360dpi x 360dpi, 720dpi x 360dpi
- Ink Cartridge – 1 Ink Cartridge can print up to 1,000 labels
- Interface – USB 2.0, Ethernet
- Printer Speed – Max. 92mm /sec
- Power Supply – Embedded AC Adapter
- Media Handling Capabilities – Roll-fed or Fanfold
- Auto Cutter – Standard (full cut only)
- Reliability Of Cutter – Up to 0.75 million cuts with no maintenance/up to 1.0 million cuts with blade cleaning
- Printer Dimensions – 10.0" W x 11" D x 10.0" H

